





# HLF808/909


## INSTALAČNÍ NÁVOD / INSTALLATION INSTRUCTION





1






2






3










4






5




6



7



$\phi$  2.8mm



x 4









ST3.5x9.5


x 4



8



24 hodin



9