

DL2715

DL2815










Installation instructions
Montážní návod
Installationsanweisungen
les instructions d'installation

polysan 

Nesměřice 52
285 22 Zruč nad Sázavou
Česká republika

tel.: +420 327 585 981
fax: +420 327 585 989

www.polysan.net

<p>1</p>  <p>6Pcs</p>	<p>2</p>  <p>6Pcs</p>	<p>3</p>  <p>2Pcs</p>
<p>4</p>  <p>2Pcs</p>	<p>5</p>  <p>6Pcs</p>	<p>6</p>  <p>1Pc</p>
<p>7</p>  <p>2Pcs</p>	<p>8</p>  <p>2Pcs</p>	<p>9</p>  <p>1Pc</p>

TOOLS REQUIRED

